VAP©RTEK® V

Vapor Shark® Instructions For Use



Fig. 3

Place unit on a firm, stable surface in a relatively high location. Unlatch case & pull out membrane rack.

Adjust air inlet by

clockwise to loosen

lever. Move the lever

up & down to adjust

rotating dial

air flow.



Remove membrane from outer plastic shipping bag. Unfold membrane & place into the rack. Wash hands after handling membranes.



odor-neutralizing dry vapor for permanent odor control. It does not produce ozone, hydroxyl, or any added moisture. This product is safe to use in occupied spaces. For use instructions, safety guidelines, and membrane best practices, please visit us online.

This unit delivers





For maximum performance, replace membranes after 270 hours of use. Do not allow membranes to contact finished surfaces; damage from oils may occur.

Click the On/Off

button into the On

use, preserve membrane life by

closing all inlet

openings.

position. When not in

FOR USE & OPERATION MANUAL VISIT

WWW.VAPORTEK.COM